

NOTE SA-1–9 PLAY-REC SWITCH (REC POSITION)
SB-1–8 TAPE-RADIO SLEEP SWITCH (TAPE POSITION)
SC-1–5 MONO STEREO WIDE SWITCH (STEREO POSITION)
SD-1 BEAT CUT SWITCH ("1" POSITION)
SE-1–2 MOTOR SWITCH (ON POSITION)
VOLTAGE VALUE ARE MEASURED WITH NO SIGNAL
USING V T V M. ( ) VALUE ARE AT PEC POSITION.
LAST NO. R259, 359, 410.
C251, 361, 430

www.radiomuseum.org; upload by Carlos A. Pieroni-García; download by radko dimfv; Sat Apr 17 09:42:57 CEST 2021 [5760 x 4056, 287kb]; ID=2101800